


SHARP

OPERATION MANUAL



HIGH POWER BLENDER
MODEL EMC-15

CONTENTS	PAGE
USAGE PRECAUTIONS	10
DESCRIPTION OF PARTS	11
SPECIFIC INFORMATION	12
HOW TO USE	13
MOTOR PROTECTION SYSTEM	15
HOW TO KEEP THE POWER CORD	15
CLEANING AND MAINTENANCE	16

Please see the date of manufacture marked on the product

Thank you for your trust in products of
Thai City Electric Co., Ltd.
In order to use products in efficiency way.
Please read the instruction manual carefully
before using this appliance.



Scan for cookbook

USAGE PRECAUTIONS

Please read the warning and cautions carefully before using this appliance and comply strictly for your own safety and to prevent the damage that may occur on your property.

WARNING


- 1 Do not switch on when the blender jug is not attached with the jug support.
- 2 Do not remove the blender jug while unit is running.
- 3 Do not use sharp material such as polished fiber to clean this appliance. Wipe it with soft damp cloth.
- 4 **Very important** : Do not rinse or immerse the motor housing in water because it may cause electric shock and material damage.
- 5 Do not place any material or hand inside the blender jug when the unit is operating.
- 6 Do not leave the unit during operation.
- 7 Always unplug the appliance from the wall outlet before cleaning or when not in use.
- 8 If the appliance is malfunction. Do not try to repair this appliance. For your own safety and using this appliance with high efficiency, contact the nearest SHARP service facility for repair.
- 9 Always switch off before removing the blender jug from jug support.
- 10 Do not plug in if you have wet hands because it may cause injury from leakage current.
- 11 This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- 12 Children should be supervised to ensure that they do not play with the appliance.
- 13 The appliance is intended to be used for commercial applications, for example in kitchens of restaurants, canteens, hospitals and commercial enterprises such as bakeries, but not for continuous mass production of food.

CAUTIONS

- 1 In case the power cord is broken, it must be replaced by manufacturer or appointed service providers or equivalent professionals to avoid any damages.
- 2 Keep the appliance out of reach of children to protect them from sharp blades.
- 3 Do not exceed the maximum capacity of the blender jug.
- 4 High temperature ingredients should be cool down before filling in the blender jug.
- 5 Always handle plug on safety part when plug in or unplug. Never pull the power supply cord to disconnect plug from the wall outlet because it may cause the power cord damage.
- 6 Do not plug in other electronic equipment on the same wall outlet the wall outlet will overheat and lead to fire.

10

DESCRIPTION OF PARTS



11

SPECIFIC INFORMATION

MODEL	EMC-15
Blender jug capacity (L)	2
Power consumption (W)	1,200
Rated voltage (V)	220
Rated frequency (Hz)	50
Product dimension (WxHxD) (mm.)	216 x 549 x 243
Total weight (Kg)	4.1
Rust-free stainless steel blades	3 levels 6 blades
Accessories	Stirring rod

*Detail is subject to change without prior notice.

12

HOW TO USE


Be sure that the rated voltage is 220V only before use.

Instructions for using the stirring rod

Insert the stirring rod through the hole on the jug cover cap to stir the ingredients in blender jug.

Instructions for covering the jug cover cap

Put the jug cover cap on the jug cover and turn it to the "LOCK" position (as shown in the picture) until it lock firmly.




Speed selection

1. Switch ON/OFF
2. Adjustment button MIN-MAX (only use when already switch on the blender)
3. "Switch PULSE" press hold this button to maximize speed.
Release to return to normal speed.

Note Start blending on low speed and slowly increase to the maximum speed.

PANEL



13

USING YOUR BLENDER

- 1 Add all required ingredients to the jug.
Note The maximum capacity of the blender 2 L.
- 2 Place the jug on the jug support which can place on 4 positions.
- 3 Put the jug cover on the top of the jug and plug in power cord properly.
• Please see "Instructions for using the stirring rod" and "Instructions for covering the jug cover cap".
Note Make sure the switch is at the "OFF" position every time before plug in.
- 4 Turn the switch to the "ON" position or press "Switch PULSE" for quick blending.
You can use the mixing stirring rod if the ingredients are quite sticky such as frozen.
• Please see "Speed selection".
Note Do not use the blender without the jug cover.
Do not operate the motor continuously for more than 4 minutes at a time. Allow the motor to rest for 2 minutes before continuing.
- 5 Turn the switch to the "OFF" position when finished using. Then remove the jug from its jug support.


14

MOTOR PROTECTION SYSTEM

This jug is equipped with a motor protection system that will switch off the motor in case of an overload condition. Turn off the appliance and then unplug it. Reduce some of the ingredients and allow the appliance to cool down for 15 minutes.


Press "RESET" switch backside that the product can continue using.

- If the product still does not work, please contact the company or authorized engineer in this manual.



HOW TO KEEP THE POWER CORD

You can store excess main cord at the back of the appliance by roll the cord into the cord storage compartment.



Note Periodically check the power cord and plug for any sign of damage.

15


CLEANING AND MAINTENANCE

Blender jug

- Pour half jug with water filled with few drops of detergent. Then, cover the jug with the jug cover and place it on the jug support. Push the PULSE button a few times.
- Detach the jug from the jug support. Rinse them with clean water and dry them with soft dry cloth.

Jug cover


- Wash jug cover in warm soapy water. Rinse and dry thoroughly.



Note Use extreme care when handling bladed. Do not touch the blades with your fingers as the blades are very sharp and can cause injury if touched.

Motor housing

- Use a clean damp cloth to clean the motor housing.



Sole Distributor in Thailand



THAI CITY ELECTRIC CO., LTD.
1643/4 New Petchburi Rd., Makrasin, Ratchathewi, Bangkok 10400
Tel. 0 2333 3111 Call Center 0 2254 5000
E-mail : callcenter@thacity.co.th

16

คิดบวก ทำบวก
เพื่อเด็กฯ และสังคมไทย
WWW.THACITY4SOCIAL.COM

www.thacity.co.th
www.sharp-weecub.com
www.facebook.com/sharpweecub

MANUFACTURED BY WESTERN APPLIANCES CO., LTD.
97 Moo 20 Sala Daeng, Bang Nam Piao, Chachoengsao 24000

