


# SHARP

## OPERATION MANUAL



BLENDER  
MODEL EM-14

CONTENTS	PAGE
USAGE PRECAUTIONS	10
DESCRIPTION OF PARTS	11
SPECIFIC INFORMATION	11
HOW TO USE	12
MOTOR PROTECTION SYSTEM	12
CLEANING AND MAINTENANCE	15
HOW TO KEEP THE POWER CORD	16

Please see the date of manufacture marked on the product  
Thank you for your trust in products of Thai City Electric Co., Ltd.  
In order to use blender in efficiency way. Please read the instructions manual carefully before using this appliance.

### USAGE PRECAUTIONS

Please read the warning and cautions carefully before using this appliance and comply strictly for your own safety and to prevent the damage that may occur on your property.


#### WARNING

- Do not switch on when the blender jug or the grinder is not attached to the motor housing.
- Do not remove the blender jug or the grinder is still operating.
- Do not use sharp material such as polished fiber to clean this appliance. Use cloth.
- The grinder is not appropriate to grind hard ingredients such as ice cubes as well as liquid ingredients.
- Very important :** Do not rinse or immerse the motor housing in water because it may cause electric shock and material damage.
- Do not place any material or hand inside the blender jug when the unit is operating.
- Do not leave the unit during operation.
- Always unplug the appliance from the outlet before cleaning or when not in use.
- If the appliance is malfunction. Do not try to repair this appliance. For your own safety and using this appliance with high efficiency, contact the nearest SHARP service facility for repair.
- Always switch off before removing the blender jug or the grinder from motor housing.
- Do not plug in if you have wet hands because it may cause injury from leakage current.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

#### CAUTIONS

- In case of the power cord is broken, it must be replaced by manufacturer or appointed service providers or equivalent professionals to avoid any damages.
- Keep out of reach of children to protect them from sharp blades.
- Do not exceed the maximum capacity of the blender jug or the grinder.
- High temperature ingredients should be cooled down before filling in the blender jug or the grinder.
- Always handle plug on safety part when plug in or unplug. Never pull the power supply cord to disconnect plug from the socket because it may cause the power cord damage.
- Do not plug in other electronic equipment in the same socket because the socket will overheat and may result in fire.

### DESCRIPTION OF PARTS




### SPECIFIC INFORMATION

MODEL	EM-14
Blender jug capacity (ml)	1,000
Grinder cup capacity (g)	50
Power consumption (W)	350
Rated voltage (V)	220
Rated frequency (Hz)	50
Total weight (Kg)	1.5
Product dimension (W x H x D) (mm)	198 x 360 x 175
Switch	3 modes (PULSE/OFF/ON)
Rust-free stainless steel blades	4 blades
Accessories	Stirrer

\* Detail is subject to change without prior notice.

### HOW TO USE

#### Speed selection



#### Instructions for covering the jug cover onto the top of blender

Cover the blender jug cover (as shown in the picture) and attach locking teeth to blender by rotating in clockwise direction until close firmly.



#### Instructions for using the stirrer

Insert the stirrer through the hold on the jug cover to stir the ingredients in blender jug.



### MOTOR PROTECTION SYSTEM

In the event of an overload condition, the motor protection system will shut down the motor immediately. To reset the appliance in case of auto stop protection due to overload, follow the steps below:

- Turn off the appliance and then unplug it.
- Remove some of the ingredients or add some liquid to reduce the load.
- Allow the appliance to cool down for 15 minutes.
- Connect the power plug to the power supply.
- Turn on the appliance to start processing again.

### USING YOUR BLENDER

- 1 Add all required ingredients to the blender jug.  
**Note** • The maximum capacity of the blender 1,000 ml  
• Do not use the ice cubes.
- 2 Place the blender jug on the motor housing and rotate the jug in clockwise direction until locked.  
**Note** If the blender jug is not correctly locked, the motor will not work.
- 3 Push the jug cover onto the top of the blender jug and plug in power cord properly.  
• Please see in "instruction for covering the jug cover onto the top of blender"  
**Note** Make sure the switch is at the OFF position every time before plug in.
- 4 Turn the switch to the ON, PULSE position to start using the blender.  
• Please see in "Speed selection"  
**Note** Do not use the blender without the jug cover. Do not operate the blender for longer than 2 minutes. After each 2 minutes session the blender must be allowed to cool down at least 1 minute before next operation.
- 5 Turn the switch to the OFF position when finish using.
- 6 Rotate the blender jug as anti-clockwise direction and lift it off the motor housing.

### USING YOUR GRINDER

- 1 Turn the grinder cup up and add the desired ingredients to the cup.  
**Note** The grinder cup is not appropriate to grind some liquid ingredients.
- 2 Cover with the grinder base turn anti-clockwise to lock tightly.
- 3 Place the grinder cup on the motor housing and turn clockwise until it locked.  
**Note** If the grinder cup is not correctly locked, the motor will not work
- 4 Plug in power cord properly.  
**Note** Please ensure that switch is at the OFF position before plug in.
- 5 Turn the switch to the ON, PULSE position to start using the blender.  
**Note** Do not operate the grinder for longer than 2 minutes. After each 2 minutes session the grinder must be allowed to cool down at least 1 minute before next operation.
- 6 Turn the switch to the OFF position when finish using.
- 7 Rotate the grinder cup as anti-clockwise direction and lift it off the motor housing.

### CLEANING AND MAINTENANCE


- |                           |  |
|---------------------------|--|
| Blender jug               | Fill a half jug blender of water or mix with small amount of dishwashing liquid and cover with the jug cover. Place on the motor housing then turn the switch to PULSE position for a moment and release, repeat it. |
| Blender jug and Jug cover | Lift the blender jug away from the base. Rinse with clean water and dry thoroughly with soft dry cloth.  |

#### Note

Take care when handing the sharp blade. It may cause injury particularly when cleaning.


#### Grinder base and grinder cup

Rinse with clean water and dishwashing liquid, use soft brush to clean then dry thoroughly with soft dry cloth.




#### Motor housing

Use a clean damp cloth to clean the motor housing.



### HOW TO KEEP THE POWER CORD

After use, keep the power cord into cord storage and insert the power cord into lock position.



#### Note

Do not keep the power cord when the motor housing is still hot. Periodically check the power cord and plug for any sign of damage.

Sole Distributor in Thailand

THAI CITY ELECTRIC CO., LTD.  
1643/4 New Petchburi Rd., Makasani, Ratchathewi, Bangkok 10400  
Tel. 0 2333 3111 Call Center 0 2254 5000  
E-mail : callcenter@thaicity.co.th

คิดบวก ทำบวก  
เพื่อเด็ก ๆ และสังคมไทย  
www.thaicity4social.com

www.thaicity.co.th  
www.sharp-weedclub.com  
www.facebook.com/sharpweedclub